




WIRE IDENTIFICATION

IDENTIFICACIÓN DE LOS CABLES

GD = Ground / Tierra

LT = Left turn / Direccional Izquierda

AX = Auxiliary / Auxiliar

EB = Electric brakes / Eléctrico del Freno

TM = Tail / Luces Traseras

RT = Right turn / Direccional Derecha

BU = Back up / Reversa

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
 - A heavy duty flasher may be required to eliminate rapid flashing.
 - Always unplug boat trailer connector before backing trailer into the water.
- * If your Nissan vehicle did not come with a factory 7-way, you must install 2 relays (#2523079945 and #2523079964), purchased from your local Nissan dealer.

CONSEJOS:

- La aplicación regular de grasa a las terminales de los cables del remolque ayudará a prevenir la corrosión.
 - Se puede requerir una señal de destello de alta potencia para eliminar que las luces destellen rápidamente.
 - Siempre desconecte el conector del remolque de botes antes de retroceder el remolque dentro del agua.
- * Si su vehículo Nissan no está equipado con el conector de fábrica de 7 vías, Usted necesita instalar 2 relevadores (#2523079945 y #2523079964), comprados de su distribuidor Nissan local.